guide.md 2024-03-09

A soil moisture sensor uses a pair of electrodes to measure the volumetric water content of the soil. The sensor has an adjustable threshold that can be used to detect the moisture level within a certain range. The sensor can be used to detect the presence of moisture in the soil, or to measure the moisture level in a certain area.

Hardware


- Soil Moisture Sensor probes
- Soil Moisture Sensor module
- Arduino
- Jumper Wires

Circuit

Connect the soil moisture sensor to the Arduino as shown in the diagram. This diagram doesn't show it, but you need to connect the module to the sensor separately. Here is a table of the connections for your reference:

Soil Moisture Sensor Module		Arduino
VCC		5V
GND		GND
A0		Analog Pin A0
Module	Probe	
VCC	VCC	
GND	GND	

guide.md 2024-03-09



You're free to use any analog pin for the A0 pin. Just make sure to update the pin number in the code, as shown below in the void setup() function.

```
void setup() {
   initializeSoilMoistureSensor(A0); // Initialize the soil moisture
sensor on analog pin A0
}
```